

Cantilever Parasols

Alexander Rose cantilever parasols are easily operated with a simple crank and tilt mechanism, allowing you to angle the canopy to provide effective shade from the sun. They are free standing, which allows you to position the furniture underneath rather than around a central pole.

We recommend that the parasol is not left up in windy conditions, ensure the parasol is closed when not in use as it can be damaged and void the warranty. It is essential to use an Alexander Rose base to add stability.

Maintenance

To clean your parasol we recommend using a soft bristle brush and warm soapy water, the canopy can be kept on the frame whilst doing this.

For more stubborn stains the canopy can be removed and washed at 30°. Once washed it is important to put the canopy back on the frame to dry fully.

Once dried, spray with our Fabric Shield which will add a protective layer, helping repel water and prevent staining.

Technical Information

The frame is made from brushed powder coated aluminium. The canopy fabric is made from Polyester. We recommend sunshades are covered or stored in a dry environment throughout the winter months.

We are able to supply night covers and spare canopies, please visit: parts.alexander-rose.co.uk.

