Hardwood Parasols

Alexander Rose hardwood parasols are operated using a pulley and locking pin system. Simply pull the rope down to raise your parasol up to the desired height and place the brass pin in one of the pole holes to secure. To lower the parasol remove the locking pin and slowly let the rope pass through your hands until the canopy is folded. We recommend that the parasol is not left up in windy conditions, ensure the parasol is closed when not in use as it can be damaged and void the warranty. It is essential to use an Alexander Rose base to add stability.

Maintenance

To clean your parasol we recommend using a soft bristle brush and warm soapy water, the canopy can be kept on the frame whilst doing this.

For more stubborn stains the canopy can be removed and washed at 30c. Once washed it is important to put the canopy back on the frame to dry fully.

We are able to supply spare night covers and canopies, please visit: parts.alexander-rose.co.uk.

Technical Information

The frame is made from Eucalyptus timber and has an oiled finish. The canopy fabric is made from Polyester. All hardwood parasols come with a night cover made from Ripstop Polyester.

We recommend sunshades are covered or stored in a dry environment throughout the winter months.







